



# **ASICamera2 Software Development Kit**

**Revision:2, 8  
2018. 8. 8**

All material in this publication is subject to change without notice and is copyright  
Zhen Wang Optical company.



# Table of Contents

<b>1 Introduction</b> .....	4
<b>2 Definition of enum-type and struct</b> .....	4
2.1 typedef enum ASI_BAYER_PATTERN .....	4
2.2 typedef enum ASI_IMG_TYPE.....	5
2.3 typedef enum ASI_GUIDE_DIRECTION.....	5
2.4 typedef enum ASI_FLIP_STATUS .....	5
2.5 typedef enum ASI_CAMERA_MODE.....	5
2.6 typedef enum ASI_ERROR_CODE .....	5
2.7 typedef enum ASI_BOOL.....	6
2.8 typedef struct _ASI_CAMERA_INFO .....	6
2.9 typedef enum ASI_CONTROL_TYPE.....	6
2.10 typedef struct _ASI_CONTROL_CAPS.....	7
2.11 typedef enum ASI_EXPOSURE_STATUS.....	7
2.12 typedef struct _ASI_ID .....	7
2.13 typedef struct _ASI_SUPPORTED_MODE .....	8
<b>3 Function declaration</b> .....	8
3.1 ASIGetNumOfConnectedCameras .....	8
3.2 ASIGetCameraProperty.....	8
3.3 ASIOpenCamera .....	8
3.4 ASIInitCamera .....	8
3.5 ASICloseCamera.....	8
3.6 ASIGetNumOfControls.....	8
3.7 ASIGetControlCaps .....	9
3.8 ASIGetControlValue .....	9
3.9 ASISetControlValue .....	9
3.10 ASISetROIFormat .....	9
3.11 ASIGetROIFormat .....	9
3.12 ASISetStartPos .....	10
3.13 ASIGetStartPos .....	10
3.14 ASIGetDroppedFrames .....	10
3.15 ASIEnableDarkSubtract .....	10
3.16 ASIDisableDarkSubtract .....	10
3.17 ASIStartVideoCapture .....	10
3.18 ASIStopVideoCapture .....	11
3.19 ASIGetVideoData.....	11
3.20 ASIPulseGuideOn .....	11
3.21 ASIPulseGuideOff .....	11
3.22 ASIStartExposure .....	11
3.23 ASIStopExposure .....	11
3.24 ASIGetExpStatus.....	11
3.25 ASIGetDataAfterExp .....	12
3.26 ASIGetID .....	12
3.27 ASISetID .....	12
3.28 ASIGetProductIDs .....	12
3.29 ASIGetSDKVersion .....	12
3.30 ASIGetCameraSupportMode .....	12
3.31 ASIGetCameraMode .....	12
3.32 ASISetCameraMode.....	12
3.33 ASISendSoftTrigger .....	12
<b>4 Suggested call sequence</b> .....	13
4.1 Initialization .....	13



4.2 Get and set control value.....	13
4.3 Camera mode .....	13
4.4 Capture image .....	13
4.5 Close camera.....	14



## Change History

Change date	revision	comment
2018.8.8	2.8	Add API Trigger
2018.5.3	2.7	Add API ASIGetSDKVersion Add BitDepth to ASI_CAMERA_INFO
2017.9.1	2.6	Remove ASI_CONTROL_TYPE: ASI_AUTO_MAX_EXP_MS, unit of ASI_AUTO_MAX_EXP is changed to ms
2017.8.8	2.5	Modify ASIEnableDarkSubtract
2017.6.26	2.4	Modify ASIGetVideoData: iWaitms
2017.5.2	2.3	Correct description of ASIGetCameraProperty
2017.4.12	2.2	Edit content
2017.2.24	2.1	Add ASI_CONTROL_TYPE: ASI_AUTO_MAX_EXP_MS
2016.12.9	2.0	Add ASI_CONTROL_TYPE: ASI_ANTI_DEW_HEATER Add ASIGetProductIDs
2016.9.19	1.3	Add ASI_CONTROL_TYPE: ASI_PATTERN_ADJUS, etc Add ASIInitCamera

## 1 Introduction

This Software Development Kit (SDK) describes a set of functions that can be used to operate the ASI line of serial cameras, via C, C++, C# and other development tools, and is suitable to be run under Windows, Linux, and OSX operating systems for either x86 or x64. The “2” brings the added functionality over previous versions of handling multiple ASI cameras within the same application.

Header file: ASICamera2.h

Under Windows the import library and dynamic library: ASICamera2.lib、ASICamera2.dll

Under Linux the dynamic library and static library: ASICamera2.so、ASICamera2.a

Under OSX the dynamic library and static library: ASICamera2.dylib、ASICamera2.a

Installation method:

Under Windows, extract the downloaded zip file to any directory, and add the DLL's path to the system environment variables, sometimes logout and re-login is required. You may also place the DLL in the folder containing the application's executable.

## 2 Definition of enum-type and struct

Several internal constants have been defined for the SDK.

2.1 typedef enum ASI\_BAYER\_PATTERN

```
{  
    ASI_BAYER_RG=0,  
    ASI_BAYER_BG,  
    ASI_BAYER_GR,  
    ASI_BAYER_GB  
}ASI_BAYER_PATTERN;
```

Bayer filter type



## 2.2 typedef enum ASI\_IMG\_TYPE

```
{  
    ASI_IMG_RAW8 = 0, // Each pixel is an 8-bit (1 byte) gray level  
    ASI_IMG_RGB24, // Each pixel consists of RGB, 3 bytes totally (color cameras only)  
    ASI_IMG_RAW16, // 2 bytes for every pixel with 65536 gray levels  
    ASI_IMG_Y8, // monochrome mode, 1 byte every pixel (color cameras only)  
    ASI_IMG_END = -1  
  
}ASI_IMG_TYPE;  
Image type
```

## 2.3 typedef enum ASI\_GUIDE\_DIRECTION

```
{  
    ASI_GUIDE_NORTH=0,  
    ASI_GUIDE_SOUTH,  
    ASI_GUIDE_EAST,  
    ASI_GUIDE_WEST  
}ASI_GUIDE_DIRECTION;  
Moving direction when guiding
```

## 2.4 typedef enum ASI\_FLIP\_STATUS

```
{  
    ASI_FLIP_NONE = 0, // no flip  
    ASI_FLIP_HORIZ, // horizontal image flip  
    ASI_FLIP_VERT, // vertical image flip  
    ASI_FLIP_BOTH, // horizontal + vertical image flip  
}ASI_FLIP_STATUS;  
Image flip
```

## 2.5 typedef enum ASI\_CAMERA\_MODE

```
{  
    ASI_MODE_NORMAL = 0,  
    ASI_MODE_TRIG_SOFT_EDGE,  
    ASI_MODE_TRIG_RISE_EDGE,  
    ASI_MODE_TRIG_FALL_EDGE,  
    ASI_MODE_TRIG_SOFT_LEVEL,  
    ASI_MODE_TRIG_HIGH_LEVEL,  
    ASI_MODE_TRIG_LOW_LEVEL,  
    ASI_MODE_END = -1  
}ASI_CAMERA_MODE;  
Camera Mode
```

## 2.6 typedef enum ASI\_ERROR\_CODE

```
{  
    ASI_SUCCESS = 0, // operation was successful  
    ASI_ERROR_INVALID_INDEX, // no camera connected or index value out of boundary  
    ASI_ERROR_INVALID_ID, // invalid ID  
    ASI_ERROR_INVALID_CONTROL_TYPE, // invalid control type  
    ASI_ERROR_CAMERA_CLOSED, // camera didn't open  
    ASI_ERROR_CAMERA_REMOVED, // failed to find the camera, maybe the camera has been  
    removed  
    ASI_ERROR_INVALID_PATH, // cannot find the path of the file
```



```
ASI_ERROR_INVALID_FILEFORMAT,  
ASI_ERROR_INVALID_SIZE, //wrong video format size  
ASI_ERROR_INVALID_IMGTYPe, //unsupported image format  
ASI_ERROR_OUTOF_BOUNDARY, //the startpos is outside the image boundary  
ASI_ERROR_TIMEOUT, //timeout  
ASI_ERROR_INVALID_SEQUENCE, //stop capture first  
ASI_ERROR_BUFFER_TOO_SMALL, //buffer size is not big enough  
ASI_ERROR_VIDEO_MODE_ACTIVE,  
ASI_ERROR_EXPOSURE_IN_PROGRESS,  
ASI_ERROR_GENERAL_ERROR, //general error, eg: value is out of valid range  
ASI_ERROR_END  
}ASI_ERROR_CODE;  
Returned error code
```

2.7 typedef enum ASI\_BOOL  
{  
    ASI\_FALSE =0,  
    ASI\_TRUE  
}ASI\_BOOL;  
True or false

2.8 typedef struct \_ASI\_CAMERA\_INFO  
{  
    char Name[64]; //the name of the camera, you can display this to the UI  
    int CameraID; //this is used to control everything of the camera in other functions. Start from 0.  
    long MaxHeight; //the max height of the camera  
    long MaxWidth; //the max width of the camera  
  
    ASI\_BOOL IsColorCam;  
    ASI\_BAYER\_PATTERN BayerPattern;

    int SupportedBins[16]; //1 means bin1 which is supported by every camera, 2 means bin 2 etc.. 0  
    is the end of supported binning method  
    ASI\_IMG\_TYPE SupportedVideoFormat[8]; //this array will content with the support output  
    format type.IMG\_END is the end of supported video format

```
    double PixelSize; //the pixel size of the camera, unit is um. such like 5.6um  
    ASI_BOOL MechanicalShutter;  
    ASI_BOOL ST4Port;  
    ASI_BOOL IsCoolerCam;  
    ASI_BOOL IsUSB3Host;  
    ASI_BOOL IsUSB3Camera;  
    float ElecPerADU;  
    int BitDepth; //the actual ADC depth of image sensor  
    ASI_BOOL IsTriggerCam;  
    char Unused[16];  
} ASI_CAMERA_INFO;  
Camera information
```

2.9 typedef enum ASI\_CONTROL\_TYPE  
{  
    ASI\_GAIN = 0, //gain  
    ASI\_EXPOSURE, //exposure time (microsecond)



ASI\_GAMMA,//gamma with range 1 to 100 (nominally 50)  
ASI\_WB\_R,//red component of white balance  
ASI\_WB\_B,// blue component of white balance  
ASI\_BRIGHTNESS,//pixel value offset (a bias, not a scale factor)  
ASI\_BANDWIDTHOVERLOAD,//The total data transfer rate percentage  
ASI\_OVERCLOCK,//over clock  
ASI\_TEMPERATURE,// sensor temperature, 10 times the actual temperature  
ASI\_FLIP,/image flip  
ASI\_AUTO\_MAX\_GAIN,/maximum gain when auto adjust  
ASI\_AUTO\_MAX\_EXP,/maximum exposure time when auto adjust, unit is micro seconds  
ASI\_AUTO\_MAX\_BRIGHTNESS,/target brightness when auto adjust  
ASI\_HARDWARE\_BIN,/hardware binning of pixels  
ASI\_HIGH\_SPEED\_MODE,/high speed mode  
ASI\_COOLER\_POWER\_PERC,/cooler power percent(only cool camera)  
ASI\_TARGET\_TEMP,/sensor's target temperature(only cool camera), don't multiply by 10  
ASI\_COOLER\_ON//open cooler (only cool camera)  
ASI\_MONO\_BIN,/lead to a smaller grid at software bin mode for color camera  
ASI\_FAN\_ON,/only cooled camera has fan  
ASI\_PATTERN\_ADJUST./currently only supported by 1600 mono camera  
ASI\_ANTI\_DEW\_HEATER  
}ASI\_CONTROL\_TYPE;  
Camera control type

## 2.10 typedef struct \_ASI\_CONTROL\_CAPS

```
{  
    char Name[64]; /control type name, like "Gain" "Exposure"..."  
    char Description[128]; //control parameter description  
    long.MaxValue;//maximum value  
    long.MinValue;//minimum value  
    long.DefaultValue;//default value  
    ASI_BOOL IsAutoSupported; //is auto adjust supported?  
    ASI_BOOL IsWritable; //can be adjusted, for example sensor temperature can't be modified  
    ASI_CONTROL_TYPE ControlType;//control type ID  
    char Unused[32];  
} ASI_CONTROL_CAPS;
```

Capacity or value ranges of control type

note: maximum and minimum value of ASI\_TEMPERATURE is multiplied by 10

## 2.11 typedef enum ASI\_EXPOSURE\_STATUS

```
{  
    ASI_EXP_IDLE = 0,//idle, ready to start exposure  
    ASI_EXP_WORKING//exposure in progress  
    ASI_EXP_SUCCESS,// exposure completed successfully, image can be read out  
    ASI_EXP_FAILED,// exposure failure, need to restart exposure  
}ASI_EXPOSURE_STATUS;
```

Use under snap shot mode to obtain exposure status

## 2.12 typedef struct \_ASI\_ID

```
{  
    unsigned char id[8];  
}ASI_ID;
```

ID to be written into camera flash, 8 bytes totally



```
2.13 typedef struct _ASI_SUPPORTED_MODE
{
    ASI_CAMERA_MODE SupportedCameraMode[16];// this array will content with the support
    camera mode type.ASI_MODE_END is the end of supported camera mode
}ASI_SUPPORTED_MODE;
Supported mode is used to save all supported modes returned by the camera.
```

## 3 Function declaration

### 3.1 ASIGetNumOfConnectedCameras

Syntax: int ASIGetNumOfConnectedCameras()

Usage: get the count of connected ASI cameras

### 3.2 ASIGetCameraProperty

Syntax: ASI\_ERROR\_CODE ASIGetCameraProperty(ASI\_CAMERA\_INFO \*pASICameraInfo, int iCameraIndex)

Usage: get the camera's information for a specific camera index (0 is the first camera)

Description:

    ASI\_CAMERA\_INFO \*pASICameraInfo: pointer to the camera's info structure  
    int iCameraIndex: camera index

example code:

```
int iNumofConnectCameras = ASIGetNumOfConnectedCameras();
ASI_CAMERA_INFO **ppASICameraInfo = (ASI_CAMERA_INFO**) malloc
(sizeof(ASI_CAMERA_INFO *)*iNumofConnectCameras);
for(int i = 0; i < iNumofConnectCameras; i++)
{
    ppASICameraInfo[i] = (ASI_CAMERA_INFO *)malloc(sizeof(ASI_CAMERA_INFO ));
    ASIGetCameraProperty(ppASICameraInfo[i], i);
}
```

Notes:

    Camera name can be obtained before the camera is opened with ASIOpenCamera

### 3.3 ASIOpenCamera

Syntax: ASI\_ERROR\_CODE ASIOpenCamera(int iCameraID)

Usage: open camera of a specific camera ID. This will not affect any other camera which is capturing.  
This should be the first call to start up a camera.

### 3.4 ASIInitCamera

Syntax: ASI\_ERROR\_CODE ASIInitCamera (int iCameraID)

Usage: initialize the specified camera ID, this API only affect the camera you are going to initialize  
and won't affect other cameras. This should be the second call to start up a camera.

### 3.5 ASICloseCamera

Syntax: ASI\_ERROR\_CODE ASICloseCamera(int iCameraID)

Usage: close a specific camera ID so that its resources will be released. This should be the last call to  
shut down a camera.

### 3.6 ASIGetNumOfControls

Syntax: ASI\_ERROR\_CODE ASIGetNumOfControls(int iCameraID, int \* piNumberOfControls)

Usage: get the number of control types for the specific camera ID



### 3.7 ASIGetControlCaps

Syntax: ASI\_ERROR\_CODE ASIGetControlCaps(int iCameraID, int iControlIndex,  
ASI\_CONTROL\_CAPS \* pControlCaps)

Usage: get control type's capacity or range of values for a specific control index

Description:

int iCameraID: camera ID

int iControlIndex: control index

ASI\_CONTROL\_CAPS \* pControlCaps: pointer to control capacity

Notes: iControlIndex is control index, is different from ControlType

### 3.8 ASIGetControlValue

Syntax: ASI\_ERROR\_CODE ASIGetControlValue (int iCameraID, ASI\_CONTROL\_TYPE  
ControlType, long \*plValue, ASI\_BOOL \*pbAuto)

Usage: get a specific control type's value as currently set for a specific camera ID

Description:

int iCameraID: camera ID

ASI\_CONTROL\_TYPE ControlType: control type

long \*plValue: pointer to the current value

ASI\_BOOL \*pbAuto: return whether the control is auto adjusted

### 3.9 ASISetControlValue

Syntax: ASI\_ERROR\_CODE ASISetControlValue(int iCameraID, ASI\_CONTROL\_TYPE  
ControlType, long lValue, ASI\_BOOL bAuto)

Usage: set a specific control type's value for a specific camera ID

Description:

int iCameraID: camera ID

ASI\_CONTROL\_TYPE ControlType: control type

long lValue: control value to be set

ASI\_BOOL bAuto: set whether the control is to be auto adjusted

Notes: when setting to auto adjust(bAuto=ASI\_TRUE), the lValue should be the current value

### 3.10 ASISetROIFormat

Syntax: ASI\_ERROR\_CODE ASISetROIFormat(int iCameraID, int iWidth, int iHeight, int iBin,  
ASI\_IMG\_TYPE Img\_type)

Usage: set region of interest (ROI) size, binning, and image type

Description:

int iCameraID: camera ID

int iWidth: image width

int iHeight: image height

int iBin: NxN binning value

ASI\_IMG\_TYPE Img\_type: image type

Return: success or error code

Notes: In general make sure iWidth%8=0, iHeight%2=0. For the USB2.0 camera ASI120, make sure iWidth\* iHeight%1024=0, otherwise the call will result in an error code.

### 3.11 ASIGetROIFormat

Syntax: ASI\_ERROR\_CODE ASIGetROIFormat(int iCameraID, int \*piWidth, int \*piHeight, int  
\*piBin, ASI\_IMG\_TYPE \*pImg\_type)



Usage: get the region of interest (ROI) values for size, binning, and image type

Description:

```
int iCameraID: camera ID  
int *piWidth: image width  
int *piHeight: image height  
int *piBin: bin value  
ASI_IMG_TYPE *pImg_type: image type
```

### 3.12 ASISetStartPos

Syntax: ASI\_ERROR\_CODE ASISetStartPos(int iCameraID, int iStartX, int iStartY)

Usage: set start position of ROI

Description:

```
int iCameraID: camera ID  
int iStartX: start position of x-axis  
int iStartY: start position of y-axis
```

Notes: the position is relative to the image after binning. call this function to change ROI area to the origin after ASISetROIFormat, because ASISetROIFormat will change ROI to the center.

### 3.13 ASIGetStartPos

Syntax: ASI\_ERROR\_CODE ASIGetStartPos(int iCameraID, int \*piStartX, int \*piStartY)

Usage: get start position of ROI

Description:

```
int iCameraID: camera ID  
int *piStartX: start position of x-axis  
int *piStartY: start position of y-axis
```

Notes: the position is relative to the image after binning.

### 3.14 ASIGetDroppedFrames

Syntax: ASI\_ERROR\_CODE ASIGetDroppedFrames(int iCameraID,int \*piDropFrames)

Usage: get dropped frames' count during video capture

### 3.15 ASIEnableDarkSubtract

Syntax: ASI\_ERROR\_CODE ASIEnableDarkSubtract(int iCameraID, char \*pcBMPPPath)

Usage: enable dark subtraction function

Description:

```
int iCameraID: camera ID  
char * pcBMPPPath: path of dark field image(.bmp)  
Return: success or error code
```

Notes: dark field image is obtained by camera's direct show driver, located in the supplied capture application's menu "video capture filter"->"ROI and others" table. The image is 8bit bitmap file, the size must be the same as the maximum resolution of camera, that is

ASI\_CAMERA\_INFO::MaxWidth and ASI\_CAMERA\_INFO::MaxHeight

### 3.16 ASIDisableDarkSubtract

Syntax: ASI\_ERROR\_CODE ASIDisableDarkSubtract(int iCameraID)

Usage: disable dark subtraction function

### 3.17 ASIStartVideoCapture

Syntax: ASI\_ERROR\_CODE ASIStartVideoCapture(int iCameraID)



Usage: start the continuous video capture

### 3.18 ASIStopVideoCapture

Syntax: `ASI_ERROR_CODE ASIStopVideoCapture(int iCameraID)`

Usage: stop the continuous video capture

### 3.19 ASIGetVideoData

Syntax: `ASI_ERROR_CODE ASIGetVideoData(int iCameraID, unsigned char* pBuffer, long lBuffSize, int iWaitms)`

Usage: after ASIStartVideoCapture (), call this function repeatedly to get images on a continuous basis. The function resets the capture to the next frame so you cannot get the same frame twice if the function is called two times in very short succession. The iWaitms is a timeout argument

Description:

`unsigned char* pBuffer`: pointer to image buffer

`long lBuffSize`: size of buffer

`int iWaitms`: wait time, unit is ms, -1 means wait forever

Notes:

If read out speed isn't fast enough, new frame is discarded, it is best to create a circular buffer for holding the imagery to operate on the frames asynchronously.

`bufSize` Byte length: for RAW8 and Y8, `bufSize >= image_width*image_height`, for RAW16, `bufSize >= image_width*image_height *2`, for RGB8, `bufSize >= image_width*image_height *3`

suggested iWaitms value: `exposure_time*2 + 500ms`

### 3.20 ASIPulseGuideOn

Syntax: `ASI_ERROR_CODE ASIPulseGuideOn(int iCameraID, ASI_GUIDE_DIRECTION direction)`

Usage: send ST4 guiding pulse, start guiding, only the camera with ST4 port support

Notes: ASIPulseGuideOff must be called to stop guiding

### 3.21 ASIPulseGuideOff

Syntax: `ASI_ERROR_CODE ASIPulseGuideOff(int iCameraID, ASI_GUIDE_DIRECTION direction)`

Usage: send ST4 guiding pulse, stop guiding, only the camera with ST4 port support

### 3.22 ASIStartExposure

Syntax: `ASI_ERROR_CODE ASIStartExposure(int iCameraID)`

Usage: start a single snap shot. Note that there is a setup time for each snap shot, thus you cannot get two snapshots in succession with a shorter time span than these values.

### 3.23 ASIStopExposure

Syntax: `ASI_ERROR_CODE ASIStopExposure(int iCameraID)`

Usage: stop a single snap shot, this API can be used for very long exposure and you don't want to wait so long such like exposure 5 minutes and you want to cancel after 1 min, then you can call this API

Notes: if exposure status is success after stop exposure, image can still be read out

### 3.24 ASIGetExpStatus

Syntax: `ASI_ERROR_CODE ASIGetExpStatus(int iCameraID, ASI_EXPOSURE_STATUS *pExpStatus)`

Usage: get snap status

Notes: after snap is started, the status should be checked continuously



### 3.25 ASIGetDataAfterExp

Syntax: ASI\_ERROR\_CODE ASIGetDataAfterExp(int iCameraID, unsigned char\* pBuffer, long lBuffSize)

Usage: get image after snap successfully

Description:

int iCameraID: camera ID

unsigned char\* pBuffer: pointer to image buffer

long lBuffSize: size of buffer

Notes: lBuffSize refer to ASIGetVideoData ()

### 3.26 ASIGetID

Syntax: ASI\_ERROR\_CODE ASIGetID(int iCameraID, ASI\_ID\* pID)

Usage: get camera id stored in flash, only available for USB3.0 camera

### 3.27 ASISetID

Syntax: ASI\_ERROR\_CODE ASISetID(int iCameraID, ASI\_ID ID)

Usage: write camera id to flash, only available for USB3.0 camera

### 3.28 ASIGetProductIDs

Syntax: int ASIGetProductIDs(int\* pPIIDs)

Usage: get the product ID of each supported camera, at first set pPIIDs as 0 and get length and then malloc a buffer to contain the PIDs

Description:

int\* pPIIDs: pointer to array of PIDs

Return: length of the array.

### 3.29 ASIGetSDKVersion

Syntax: ASICAMERA\_API char\* ASIGetSDKVersion()

Usage: get version string of SDK

### 3.30 ASIGetCameraSupportMode

Syntax: ASI\_ERROR\_CODE ASIGetCameraSupportMode(int iCameraID,

ASI\_SUPPORTED\_MODE\* pSupportedMode)

Usage: Get the camera's supported mode.

### 3.31 ASIGetCameraMode

Syntax: ASI\_ERROR\_CODE ASIGetCameraMode(int iCameraID, ASI\_CAMERA\_MODE\* mode)

Usage: Get the current camera mode.

### 3.32 ASISetCameraMode

Syntax: ASI\_ERROR\_CODE ASISetCameraMode(int iCameraID, ASI\_CAMERA\_MODE mode)

Usage: Set a mode into the camera.

### 3.33 ASISendSoftTrigger

Syntax: ASI\_ERROR\_CODE ASISendSoftTrigger(int iCameraID, ASI\_BOOL bStart)

Usage: Send a trigger signal for software simulation. When the bStart is ASI\_TRUE, the camera will start exposing. For edge trigger, there is no need to send ASI\_FALSE, and the software will reset itself when the exposure time is over. For level trigger, it needs ASI\_FALSE to stop the exposure.



## 4 Suggested call sequence

### 4.1 Initialization

Get count of connected cameras--> ASIGetNumOfConnectedCameras  
Get cameras' ID and other information like name, resolution, etc. Refreshing devices won't change this ID--> ASIGetCameraProperty  
Open camera -->ASIOpenCamera (Notes: this SDK can operate multiple cameras which are distinguished uniquely by CameraID)  
Initialize-->ASIInitCamera  
Get count of control type--> ASIGetNumOfControls  
Get capacity of every control type-->ASIGetControlCaps  
Set image size and format-->ASISetROIFormat  
Set start position when ROI-->ASISetStartPos

### 4.2 Get and set control value

    ASIGetControlValue  
    ASISetControlValue //allowed during capture except set exposure time in trigger mode

### 4.3 Camera mode

First, use the IsTriggerCam in ASI\_CAMERA\_INFO to determine if your camera has multiple modes.  
If it is false, there is no need to call these functions about the camera mode.  
Get supported mode of the camera--> ASIGetCameraSupportMode  
Set a mode --> ASISetCameraMode  
Get the mode--> ASIGetCameraMode

### 4.4 Capture image

There are two modes for capturing frames: video mode and snap shot mode. Images are captured continuously under video mode, and only a single image is captured under snap shot mode.  
If the camera is not working in normal mode, but in trigger mode, images only can be captured under video mode.

- video mode
  - Start video capture-->ASIStartVideoCapture
  - Operate on video frames as they are captured. Have the thread below signal that a new frame is available.
  - Stop video capture-->ASIStopVideoCapture

It is suggested that one should get and save data in single thread:

```
while(1)
{
    if(ASIGetVideoData == ASI_SUCCESS)(internally uses a waitFor so does not spin CPU cycles
until a frame is digitized and available)
    {
        ...
    }
}
```

- snap mode  
ASIStartExposure



```
while(1)
{
    ASIGetExpStatus(,&status)
    ...
}
Cancel exposure: ASIStopExposure
if(status ==ASI_EXP_SUCCESS)//get image if snap successfully
    ASIGetDataAfterExp
```

4.5 Close camera  
ASICloseCamera//release resource for each camera